

## AD 1 LETISKÁ - ÚVOD

### AD 1.1 VYUŽITIE LETISKA

#### 1.1.1 Všeobecné pravidlá pre využitie vojenského letiska

1.1.1.1 Za vojenské letisko sa považuje každé letisko, ktorého prevádzkovateľom sú SAF a to bez ohľadu na to, či je na tomto letisku rozhodnutím Dopravného úradu zriadený aj civilný prevádzkovateľ tohto letiska.

1.1.1.2 Za využitie vojenského letiska sa považuje pristátie na tomto letisku, ale aj priblíženie s následným odletom (za VFR) na iné letisko alebo cvičné priblíženie.

1.1.1.3 Pristátie iného než vojenského lietadla na vojenskom letisku povoľuje veliteľ Vzdušných síl. Toto ustanovenie sa nevzťahuje na pristátie akéhokoľvek lietadla v stave núdze.

1.1.1.4 Pilot civilného lietadla alebo cudzieho štátneho lietadla je pred letom povinný posúdiť, či mu podmienky na vojenskom letisku, vrátane poskytovaných leteckých služieb a poskytovaného zabezpečenia, umožnia bezpečné vykonanie letu. Pilot musí plne rešpektovať odchyľky alebo zvláštnosti, ktoré môžu byť s využitím vojenského letiska spojené.

1.1.1.5 Ďalšie informácie, pravidlá a podmienky - pozri podsekciiu GEN 1.2 Vstup, tranzit a odlet lietadla.

#### 1.1.2 Pravidlá pre civilné využitie vojenského letiska

1.1.2.1 Povinnosť podania FPL

1.1.2.1.1 Všetky lety z/na vojenské letisko musia byť vykonávané na základe podaného FPL.

1.1.2.1.2 Výnimku tvoria:

- lietadlo nútené vykonať núdzové pristátie (pilot lietadla musí jednoznačne deklarovať stav núdze),
- lietadlo vykonávajúce let bezprostredne súvisiaci so záchranou ľudského života,
- lietadlo vykonávajúce let za účelom pátrania a záchranu.

Tieto lety je možné vykonávať iba na základe odovzdaného oznámenia o lete a letového povolenia vydaného príslušným stanovišťom MIL ATC.

#### 1.1.3 Všeobecné podmienky, podľa ktorých sú letiská a príslušné zariadenia použiteľné

1.1.3.1 Vojenské letisko Malacky prevádzkuje 46. krídlo v Kuchyni:

Poštová adresa: 46. krídlo Kuchyňa  
900 52 KUCHYŇA

1.1.3.2 Vojenské letisko Prešov prevádzkuje 51. krídlo v Prešove:

Poštová adresa: 51. krídlo Prešov  
Vranovská 68  
080 01 PREŠOV

1.1.3.3 Vojenské letisko Sliač prevádzkuje 81. krídlo v Sliači:

Poštová adresa: 81. krídlo Sliač  
ČSA 1182  
962 31 SLIAČ

## AD 1. AERODROMES - INTRODUCTION

### AD 1.1 AERODROME AVAILABILITY

#### 1.1.1 General rules for use of military aerodromes

1.1.1.1 Any aerodrome operated by SAF is considered to be a military aerodrome regardless of the fact that there is also a civil operator established at such an aerodrome by means of decision of the Transport Authority.

1.1.1.2 Any landing at such an aerodrome as well as any approach with a subsequent (VFR) departure to another aerodrome or a training approach is considered to be a use of a military aerodrome.

1.1.1.3 Landing of other than military aircraft at a military aerodrome is approved by the Air Force commander. This provision shall not apply to any aircraft emergency landing.

1.1.1.4 It is the obligation of the pilot of the civil aircraft or the foreign state aircraft to consider whether the conditions at the military aerodrome, including both the aeronautical and operational services provided at such an aerodrome, enable safe flight. The pilot shall fully respect any differences or particularities that might be related to the use of the military aerodrome.

1.1.1.5 For further information, rules and conditions - see subsection GEN 1.2 Entry, transit and departure of aircraft.

#### 1.1.2 Rules for civil use of military aerodrome

1.1.2.1 Obligation to submit FPL

1.1.2.1.1 All flights from/to a military aerodrome must be carried out on basis of a filed FPL.

1.1.2.1.2 The exception is for:

- aircraft forced to carry out an emergency landing (the pilot of aircraft must unambiguously declare the state of emergency),
- aircraft carrying out flights directly related to a rescue of human life,
- aircraft carrying out a flight on purpose of search and rescue.

These flights can be carried out solely based on submission of the notification about the flight and ATC clearance issued by the appropriate MIL ATC unit.

#### 1.1.3 General conditions under which aerodromes and associated facilities are available for use

1.1.3.1 Military aerodrome Malacky is operated by 46<sup>th</sup> wing in Kuchyňa:

Postal address: 46. krídlo Kuchyňa  
900 52 KUCHYŇA  
Slovak Republic

1.1.3.2 Military aerodrome Prešov is operated by 51<sup>st</sup> wing in Prešov:

Postal address: 51. krídlo Prešov  
Vranovská 68  
080 01 PREŠOV  
Slovak Republic

1.1.3.3 Military aerodrome Sliač is operated by 81<sup>st</sup> wing in Sliač:

Postal address: 81. krídlo Sliač  
ČSA 1182  
962 31 SLIAČ  
Slovak Republic

1.1.3.4 Klasifikácia ILS na jednotlivých letiskách v Slovenskej  
Republike

1.1.3.4 ILS classification at aerodromes in the Slovak  
Republic

Letisko Aerodrome	Dráha Runway	Klasifikácia Classification
Malacky	19	CAT I
Sliac	36	IT2